



Access Point location reference tag  
(see AP tag table and AP ID coding table for code mappings)



Internal omnidirectional antenna – ceiling mount



External patch antenna – outward facing – wall / beam / column mount



External patch antenna – downward facing



Highly directional external antenna – outward facing – wall / beam / column mount



Highly directional external antenna – downward facing



Internal omnidirectional antenna – 90 deg. wall mount bracket



Internal omnidirectional antenna – wall plate surface mount



Dual external patch antennae – ceiling mount



Dual external patch antennae – outward facing – wall / beam / column mount

### AP tag table – AP types

- Y001: Cisco 1121g
- Y002: Cisco 1252
- Y003: Cisco 1142
- Y003: Cisco 3602i
- Y004: Cisco 3702i
- Y005: Cisco 3702e + AIR-ANT2566-P4W-R
- Y006: Cisco 702W
- Y007: Cisco 2602i
- Y008: Cisco 3702e + AIR-ANT2566-D4M-R
- Y009: Cisco 3702p + AIR-ANT2513-P4M-N
- Y010: Cisco 3702e + AIR-ANT2544-V4M-R
- Y011: Cisco 3802i
- Y012: Cisco 3802e + AIR-ANT2566-P4W-R
- Y013: Cisco 3802e + AIR-ANT2566-D4M-R
- Y014: Cisco 1815w
- Y015: Cisco 2802i
- Y016: Cisco 2802e + AIR-ANT2566-D4M-R
- Y017: Cisco 2802e + dual AIR-ANT2566-D4M-R

### AP ID coding (fff-nnn)

fff : floor/level served by AP installation (where ground level is 1, 2<sup>nd</sup> floor is 2, basement is B, sub-basement is B2, etc.)

nnn : AP number on floor/level (numbering starts at 001 on each floor)

	REVISION:		PROJECT NAME: <b>UIT – Infrastructure Planning Standards</b>	DRAWN BY:	ER	PROJECT #:	
	1	Original		APPROVED BY:	ER	ISSUE #: 1	
	2	Add 1815W, 2802, dual D4M		ER	DATE:	2018 07 18	DRAWING #:
	3				SCALE:	NTS	UIT-ICT-02
	4						
	5						
			DRAWING NAME: <b>Wi-Fi Symbols</b>				